



INSTRUCTIONS for MOVEMENT

- Place on surfaces that are not coarse and/or free from stones that may damage the bottom
- Avoid overlapping of the containers
- Do not overlap weights
- Move only when empty

INSTRUCTIONS for INSTALLATION

• **CONTAINER ESCLUSIVELY FOR EXTERNAL USE AS STORAGE FOR DRINKING WATER**

- Check the integrity of the container and relative accessories for any damages due to transportation and/or movement and if necessary immediately contact the seller
- **ONLY** install on a flat surface, suitable to support the weight of the full container, clean and free of stones and/or roughness that may damage the bottom.
- The bottom of the container should rest completely on a continuous surface or it may suffer irreparable damage
- Avoid installations close to heat sources
- Resistant between -30 and $+50^{\circ}\text{C}$
- The tubes should not rest on the container and/or their accessories especially if they are subject to heat variations or if they are connected to pumps, use flexible tubes and allow for adequate ventilation
- For the installation of accessories/bulkheads/gaskets perforate using relative cup drills
- Once connections have been made, inspect the tubes and the container by filling to check for any possible leaks



CONTAINER

NOT FOR TRANSPORTATION

NOT FOR BURIAL

NON OBSERVANCE OF THESE INDICATIONS

May result in deformation and/or breakage of the container and/or may compromise its duration and validity of the

GUARANTEE

FOR ANY REQUIREMENTS CONTACT THE SELLER